



BURR KING MFG. CO., INC

1220 Tamara Lane

Warsaw, MO 65355

www.burking.com

(660)438-8998 • 800-621-2748

Fax (660)438-8991



MADE IN U.S.A.



- * GRINDERS
- * BUFFERS
- * VIBRATORY
- * DISC GRINDERS

BURR KING FILTERPAK 4001 INSTRUCTION MANUAL



BURR KING MFG. CO., INC.

1220 TAMARA LANE

WARSAW MO 65355

WWW.BURRKING.COM

(660) 438-8998 s (800) 621-2748

FAX (660) 438-8991

June 21, 2007

LETTER OF AUTHENTICITY

This letter is to certify that all Burr King Belt grinders, Disc grinders, Polishing machines Vibra King Chambers and Bowls are manufactured and assembled in the United States of America.

(Tariff number 847990 criterion A)

A handwritten signature in black ink that reads "Don Mac Carthy".

Don Mac Carthy
President

See our catalog at www.burrking.com

contact us at info@burrking.com



BURR KING MFG. CO., INC.

1220 TAMARA LANE

WARSAW MO 65355

WWW.BURRKING.COM

(660) 438-8998 • (800) 621-2748

FAX (660) 438-8991

January 2012

Installation/Operating instruction for the FilterPAK 4001

The FilterPAK 4001 provides filtration of vibratory fluids via replaceable filter bags, gravity settling, and a flow over baffle. The replaceable filters are available from Burr King Manufacturing in 5, 10, 15, 25, 50, and 100-micron meshes. Select finer mesh (i.e. 10 micron vs. 100 micron) for greater filtration. Finer mesh filters will have shorter service life than filters with coarser mesh, but will provide clearer filtration and thus cleaner vibratory processing. The standard filter that is provided with the FilterPAK 4001 is 15-micron mesh.

To place your FilterPAK 4001 in service follow these instructions (if you purchased the FilterPAK 4001 as a part of a vibratory system from Burr King go to step 4):

1. Install a 1/2 (3/8 with VibraKING bowls) male barb into the drain outlet of your VibraKING chamber.
2. Connect the 1/2-inch (3/8 with VibraKING bowls) clear plastic hose between the input to the FilterPAK 4001 and the chamber output drain.
3. Secure the 1/2-inch hose to the chamber barb, and to the FilterPAK 4001 input tube with the clamps provided.
4. Route the 1/4-inch pump tube from the chamber input to the pump connection. Pass the tube and the pump power cord through the 1 inch hole in the lid of the FilterPAK 4001.
5. Connect the clear plastic hose from the chamber drain to (or through) the tube fitting on the lid of the FilterPAK 4001. If the tube ID fits over the fitting used the supplied clamp to secure.
6. Place the pump into small chamber of the FilterPak.
7. Add water to the FilterPAK 1 inch above baffle. At this fill level there are approximately 6 gallons of fluid in the FilterPAK 4001.

Do not over fill the FilterPAK.

8. Add compounds (soaps) of the type and the ratios suggested by the compound manufacturer (Burr King recommends **BKS60, and AR60 soap for de-burring and most surface moderation**). In example, if the suggested ratio is 2-oz. soap per gallon of water, add about 12 oz. of soap to the FilterPAK reservoir and mix with the 6 gallons of water previously added. We recommend that you premix all fluids.

9. Adjust the metering valve on your vibratory chamber to the desired fluid flow rate. The pump that is provided with the FilterPAK 4001 is capable of providing 140 gal./hour at a 36-inch rise. In general a fluid flow rate of 1 to 2 gallons per hour per cubic feet of chamber capacity is nominal, this flow occurs with the metering valve at about 60 degrees off line.

10. The filter in your FilterPAK 4001 will require periodic change. The length of time between changes will vary depending on the capacity of your chamber, the media type you are using, the chamber liquid flow rate, the material you are processing, the mass of your material, and naturally the mesh size of the filter you use. As a reference point a 15 micron filter with 250 pounds of P20 media in a 4.5 cubic foot chamber processing 50 pounds aluminum, at a fluid flow rate of 4 to 6 gallons/hour will sustain useable fluid flow and sludge filtration for about 12 hours. When the filter nears replacement time you will note that fluid backs up in the clear drain tube such that there is no air pocket visible. To replace the filter lift the top of the FilterPAK free, remove the filter. Install the new filter and reassemble the FilterPAK. You will find it helpful to have a bucket handy into which you should place the depleted filter (including its fluid and sludge contents). Later, after the filter has fully drained, remove the depleted filter from the bucket and dispose of the filter and its dried contents in a responsible manner.

Note: Plastic and synthetic media will foam and will require more frequent filter changes than does ceramic media. This is natural and unavoidable due to the composition of plastic media. Typically the life of filters when plastic media is used will be less than 1/2 that of filters when ceramic media is used.

11. Periodically clean out the sludge that will form in the bottom of the FilterPAK. Most of this sludge deposit will occur in the larger chamber. Do not allow the sludge to accumulate deeper than 1/2 inch in either chamber.

12. Add water and soap to your FilterPAK as required to keep the fluid level between above the pump inlet (about 4 inches minimum) and the 6-gallon mark 1 inch above the baffle. **DO NOT RUN THE PUMP DRY.** Running the pump dry may damage the pump as it will have inadequate cooling.

13. **Dispose of the depleted (filled) filters in a responsible manner.** Generally, the filter bags can be disposed in public landfills when material such as steel, iron, aluminum, and copper are processed: however, you should consult with your local authorities for specific requirements and instructions in regard to disposal of all waste materials.

Operating tips for your FilterPAK 4001

1. **During the first few hours of operation after the installation of new media:**

- The drain tube from the vibratory chamber to the FilterPAK 4001 may plug. This is a consequence of the new media sloughing off edge particles that may not gravitate into the filter bag. Should you observe particles collecting in the clear drain hose tilt the hose to allow the particles to flow into the FilterPAK 4001. Alternately, disconnect the hose and allow the particles to escape into a bucket for disposal. Reconnect the hose. If the hose becomes fully impacted the FilterPAK 4001 will pump dry prematurely and the available fluid will collect in the vibratory chamber. If this occurs it will be necessary to stopper the chamber before removing the clear drain hose to prevent spillage. It may also be necessary too forcibly dislodge the hose impaction using a rod or similar device.
- The filter bag may require changing after 2 to 4 hours of operation or less if plastic media is in use. This is a natural consequence of “break-in” of the media. Larger, coarser media will create more initial debris than will smaller finer media.
- After media “break-in” change the filter at regular intervals (see previous discussion on page 1). Keeping the filtration system clean will pay dividends in media life, reduced cycle times, and part cleanliness.

2. **Use a 5-gallon bucket** or similar container to place exhausted filters into after removal from the FilterPAK 4001. Doing thus will provide you a handy way to avoid spillage since the exhausted filter will have some liquid trapped, and also provide a place for the filter to dry in preparation for disposal. It is not uncommon to trap two or three pounds of sludge in the filter.

3. **Mix your water and compounds** (soaps) in a separate, clean bucket. Add the fluid to the FilterPAK 4001 (or to the vibratory chamber) as required. Doing thus will assure that you maintain the proper ratio of compound to water.

4. **Do not allow the pump to sit** in a layer of collected sludge in the FilterPAK 4001. The sludge will harden over time and damage the pump. Periodically, take your FilterPAK out of service and thoroughly clean out all sludge from both chambers.

5. **Periodically check the pH (acidity/alkalinity) of the vibratory fluids.** As a general rule deburring media prefers a pH of 8 to 11 (alkaline) when used on steel, aluminum, cast iron, copper, etc. Adding the recommended mixture of vibratory soap to water that is pH neutral (7.0) will typically raise the pH to the recommended 8 to 11 range. As oils and other contaminants are added as a natural consequence of the deburring process the pH may drop below the recommended level. This may result in accelerated rusting and/or other staining of your material. Should this happen replace the vibratory fluid with fresh fluid mixed per manufacturer’s instructions. There are several methods available for measuring pH. Electronic meters are the most accurate and the most expensive. Litmus paper is inexpensive and suitable for this purpose. Purchase litmus paper at drug stores, chemical supply houses, or through your local industrial supply.

6. **DO NOT USE FLUIDS OTHER THAN WATER** (with approved soaps) in the FilterPAK 4001. Doing so may create a fire or explosion hazard resulting in serious injury and/or property loss. Additionally, fluids other than water and recommended soaps may attack the urethane liner of the vibratory chamber and significantly shorten its service life. **Burr King vibratory chambers are covered by warranty that is void if unapproved fluids are used.**



BURR KING MFG. CO., INC.

1220 TAMARA LANE

WARSAW MO 65355

WWW.BURRKING.COM

(660) 438-8998 ♦ (800) 621-2748

FAX (660) 438-8991

January 2012

FilterPak 4001 – Installing Fittings on a 150/200 Vibratory Bowl



Remove supplied plugs with a 9/16" wrench.



Install 90° inlet fitting to upper hole.



Install drain plug thru the bottom of the bowl making sure that the rubber o-ring is properly seated to the bowl.



Using supplied nylon insert nut tighten against the bowl with a 9/16" wrench



Congratulations – You are now ready to hook up the supply and drain lines from your FilterPak to your bowl.



BURR KING MFG. CO., INC.

1220 TAMARA LANE

WARSAW MO 65355

WWW.BURRKING.COM

(660) 438-8998 ♦ (800) 621-2748

FAX (660) 438-8991

Technical note:

Subject: Burr King Filter PAK 4000, filters

October 2000

The Burr King Filter PAK 4000 is a closed loop compound delivery system that incorporates a high quality polyester felt membrane filter. The filter is rated at 25 gallons per hour, well over the necessary flow rate for most vibratory systems. The filter is also rated for a pressure head of 12 feet (6 PSI). Various filter mesh sizes may be used. The fluid moving through smaller mesh size filters will contain smaller particulates than will fluid passing through larger filter mesh sizes. The following data is based on Burr King P-20 ceramic media and serves as a guide for filter mesh size selection.

Filter mesh size, micron	Traps particles (note 1) larger then:	Est. effective life by BK model in hours (note 2)					
		110	150S	200S	25	45	85
5	0.0002 inches	200	80	40	10	5	2
10	0.0004 inches	200	120	60	12	7	3
15*	0.0006 inches	200	140	80	18	10	4
25	0.0012 inches	200	200	100	36	20	8
50	0.0024 inches	200	200	200	60	36	16
100	0.0048 inches	200	200	200	80	48	20
Model approximate volume (cu. ft.)		0.15	0.5	1.0	2.5	4.5	8.5

* Filter PAK 4000 units include two 15-micron filters as standard.

Note 1: Human hair is approximately 0.003 inches in diameter. Filters are rated by the size of particle that will, with high probability, be trapped. This also means that a small percentage of larger particles will escape and stay in solution.

Note 2: Effective life is the point in time when the filter flow rate drops to 50% of rated value. Effective life will vary greatly depending on the media used, flow rate metered, material being processed, and the volume and energy of the vibratory system.

Burr King recommends 15-micron filters for most ceramic media applications. We recommend 50 or 100 micron filters for most plastic media applications. When greater fluid clarity is required, or fewer residues remaining on parts is desired select a smaller filter mesh size. Compounds such as anti-rust and soaps will pass through the filters and remain in solution. The filters will trap compound additives such as plastic anti-stick beads. Remember that smaller mesh size filters will require more frequent changes.

Filters are available from Burr King by individual mesh sizes in packs of 5, 10, and 25 filters/pack.



Celebrating 60 Years in 2011

BURR KING MFG. CO., INC.

1220 TAMARA LANE

WARSAW MO 65355

WWW.BURRKING.COM - info@burrking.com

(660) 438-8998 • (800) 621-2748

FAX (660) 438-8991

Effective: March 15, 2011

Filter PAK Filter Prices

Filters sold by micron mesh size in kit quantities of 5, 10, & 25

Fine micron best for porcelain media, medium micron best for ceramic, coarse micron best for plastic medias

PART NO.	MICRON	QUANTITY	PRICE
FP-5-5	5	5	CALL
FP-5-10	5	10	CALL
FP-5-25	5	25	CALL
FP-10-5	10	5	CALL
FP-10-10	10	10	CALL
FP-10-25	10	25	CALL
FP-15-5	15	5	CALL
FP-15-10	15	10	CALL
FP-15-25	15	25	CALL
FP-25-5	25	5	CALL
FP-25-10	25	10	CALL
FP-25-25	25	25	CALL
FP-50-5	50	5	CALL
FP-50-10	50	10	CALL
FP-50-25	50	25	CALL
FP-100-5	100	5	CALL
FP-100-10	100	10	CALL
FP-100-25	100	25	CALL

**Prices/Spec. may change without notice. Prices are in US\$, outside of US consult with factory*